

Table of Contents

Management and Administration	3
--	---

Management and Administration

1. Configuration of the SWu Interface
2. SWm/SWx Authorization Mode Settings
3. SWm Authorization Interface Settings
4. SWx Authorization Interface Settings
5. S6b Authorization Interface Settings
6. S2b Tunneling Interface Settings
7. GTP Tunneling Protocol Settings