

Table of Contents

IPFIX export configuration from SSG to QoE	3
<i>Export configuration</i>	3

IPFIX export configuration from SSG to QoE



Configuration in GUI

Export configuration

IPFIX export is configured in the `fastdpi.conf` file on the DPI.

Example of minimal recommended export settings:

```
netflow=8
netflow_dev=em1
netflow_timeout=10
netflow_full_collector_type=2
netflow_full_port_swap=0
netflow_full_collector=YOUR_QOESTOR_IP:1500
ipfix_dev=em1
ipfix_tcp_collectors=YOUR_QOESTOR_IP:1501
```



Additionally, you can configure export of [NAT](#) flows, [DNS](#), [GTP](#) and [RADIUS](#).

QoE must have [receivers configured](#) for all streams.



To apply the changes, fastDPI must be restarted.

The `netflow` parameter is a bitmask and can have several different values. See more in [Set up NetFlow export by protocols, directions and billing](#).